

! WARNING

Before installing the device, always wear eye protective and point the device to a safe area, pay attention to and take care to not hit bystanders. Make sure the gas is empty and no projectiles inside before the installation.

- Always treat the device as if it is loaded.
- Always exercise muzzle awareness.
- Always practice good firing discipline.
- Always store or keep the device in a safe place away from children.
- Never leave this device in public area

! Do not shoot at people.

This device is used for expel animal only.
A-Plus is not responsible for injury, death or damage to property resulting from either intentional or accidental discharge of this device, or from its function when used for purposes or subjected to treatment for which it was not designed.

The goal of using this device is never to win a fight.
It is to survive and escape without injury. Operate this device and give yourself the best chance to escape unharmed.

I. Get Started

- 1) Unscrew the bottom 2 pins by a screw-driver.
- 2) Punch the 2 pins out
- 3) When pushing the pins out, holding down the bottom cap to avoid the bouncing of the cap.



II. Take all components Out

Take all the internal components out from the device including:

- 1) Capsule Holders x 2
- 2) Capsule Springs x 2
- 3) Main Springs x 2
- 4) Bottom Cap x 1



Bottom Cap

III. Put the Safety On

Make sure the two firing buttons are up.
Lock it by pushing the safety plate forward under the firing buttons.



IV. Load the projectiles

- 1) Insert the projectiles (.50 / .68) Rubber Ball from the rear of the device.
- 2) Insert the 2 x Main Springs into the device.



V. Load the 12g Co2 capsules

Place the 2 x 12g Co2 capsules to the holders and put the capsule spring surrounding the capsule head to avoid mis-hitting of the capsule.



VI. Assembling

Place the capsule holders back to the device by forcing it down with a solid tube comes with the package, push it hard until you hear a "click" meaning the holder is being locked in the device.

